

AIRTEC Motorsport Hyundai Kona N Catch Can Kit

Tools Required:

- Ratchet and Socket Set
- Jubilee Flexi-Driver or Flat-Blade Screwdriver
- Hose Clamp Pliers
- 21mm Spanner or Adjustable Spanner

Kit Contents:

- 1x AIRTEC Motorsport Billet Catch Can
- 1x Mounting Bracket
- 1x Pro Hose Silicone Hoses
- **Fitting Kit:**
 - 4x M5x8mm Button Head Bolts
 - 4x M5 Washers
 - 1x Hose Separator
 - 3x 25mm Jubilee Clips
 - 1x 20mm Jubilee Clip



PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT

Instructions:

1. Open the bonnet and remove the engine cover by lifting from the corner to release it from its mounting posts.



2. Assemble the catch can by using the supplied M5 hardware to attach it to the bracket, followed by installing the two take offs into the catch can. Tighten using either an adjustable or 21mm spanner.



3. Locate and remove the bolt holding the earth strap to the bodywork using a 10mm socket. Then place the catch can in place and reinstall the bolt.



4. Finally, remove the original breather hose from the vehicle using a pair of hose clamp pliers. The new supplied hoses can then be installed as shown and secured with the supplied jubilee clips. Use the supplied hose separator to position the hoses. The engine cover can then be reinstalled.

